

1:Fix the self tapping screw onto the wall

2:Connect the lamp wires to the reserved wires

3:Hang the lamp body on the self tapping screw

