

1:Connect the lamp wires to the reserved wires

2:Drive the self tapping screw onto the wall

3:Align the hole position of the lamp body with the screw cap and fix it

4:Installing bulb

5:Install the lampshade

