

Openwork Ceramic Pendant Lamp

- 1: Fix the hanging board to the ceiling
- 2: Connect the lamp wires to the reserved wires
- 3: Fix the ceiling tray and hanging board from the side
- 4: Tighten the lampshade with a ring
- 5: Installing bulb

