

1: Fix the hardware to the wall with self tapping screws

2: Connect the lamp wires to the reserved wires

3: Align the hole position and rotate to fix it

