





1





Take out the hanging plate and fix the hanging plate at the ceiling outlet position

2



3

The electric wires in the home connect to the light fixtures



4

The 4 side holes of the suction top plate above the lamp body are rotated into the mounting plate screws, so as to fix the lamp body