




Depending on the ceiling material, different screws are used to fix the hanger. Please do not directly fix the hanger on the wooden ceiling to prevent the wooden screws from loosening and causing danger. After the hanger is fixed, it must be confirmed that it can withstand a gravity of more than 60 kilograms (test pull by hand) for safety.