



Drift Adjustable Ceiling Lamp





V **a** **k** **k** **e** **r**
L I G H T I N G

www.vakkerlight.com - info@vakkerlight.com

1



Fasten the hanging board to the ceiling with screws




The wires in the home are connected to the wires in the lamps through the wire terminals

VAKKER
LIGHTING

www.vakkerlight.com - info@vakkerlight.com

2



The side screws fix the lamp body to the ceiling plate

VAKKER
LIGHTING

www.vakkerlight.com - info@vakkerlight.com