

1 Remove the mounted lamp
body from the package

2 Put it in a dry place and
use it with electricity

