

# INSTALLATION INSTRUCTIONS

Turn off the power to the main circuit panel before starting.

## CAUTION

The light source for this product is a non-replaceable LED. Do not disassemble the product, as the LED may damage your eyes.

## CAUTION

Do not immerse in water.

Failure to follow assembly instructions may result in a fire or electric shock hazard.

## WARNINGS

Pulling the light fixture out of the surface may cause personal injury and damage to the fixture and/or the mounting surface. To reduce the likelihood of injury or damage, install it only on surfaces with intact mechanical structures.

Different materials require different fittings. Always select screws and plugs specifically matched to the material.

## WARNINGS

Failure to follow assembly instructions may result in a fire or electric shock hazard.

## WARNINGS

Choking hazard. Keep the power cord at least 3 feet away from cribs, bassinets, and toddler beds.

## WARNINGS



## CARE AND MAINTENANCE

Handle with Care: Please exercise caution during assembly and cleaning to avoid scratches or breakage.

Cleaning Instructions: Do not use any chemical solvents or abrasive cleaners on the lampshade, as they may damage the finish. Use only a soft, dry cloth to remove dust.

**THIS PRODUCT IS NOT A TOY AND HAS NO PLAY VALUE.**

1



2

